

Sr.No	Rocksmith Part Number	Thread		Length		Diameter		
		A	B	mm	In	mm	In	
	<b>Adapter Coupling -Semi Bridge Type</b>							
1	C2-R22-R25-160-35	R22	R25	150	6	35	1-3/8	
2	C2-R25-R28-160-38	R25	R28	160	6-5/16	38	1-1/2	
3	C2-R25-R32-160-44	R25	R32	160	6-5/16	44	1-11/16	
4	C2-R28-R32-160-44	R28	R32	160	6-5/16	44	1-11/16	
5	C2-R32-R38-170-55	R32	R38	170	6-3/4	55	2-5/32	
6	C2-R32-T38-170-55	R32	T38	170	6-3/4	55	2-5/32	
7	C2-R38-T38-180-55	R38	T38	180	7-1/8	55	2-5/32	
8	C2-R38-T45-180-63	R38	T45	180	7-1/8	63	2-31/64	<b>A</b> <b>B</b>
9	C2-T38-T45-180-60	T38	T45	180	7-1/8	60	2-3/8	
10	C2-T45-T51-225-72	T45	T51	225	8-7/8	72	2-27/32	Adapter Coupling -Semi Bridge Type
	<b>Adapter Coupling- Full Bridge Type</b>	<b>A</b>	<b>B</b>	<b>mm</b>	<b>In</b>	<b>mm</b>	<b>In</b>	
1	C3-R22-R25-160-35	R22	R25	150	6	35	1-3/8	
2	C3-R25-R28-160-38	R25	R28	160	6-5/16	38	1-1/2	
3	C3-R25-R32-160-44	R25	R32	160	6-5/16	44	1-11/16	
4	C3-R28-R32-160-44	R28	R32	160	6-5/16	44	1-11/16	
5	C3-R32-R38-170-55	R32	R38	170	6-3/4	55	2-5/32	
6	C3-R32-T38-170-55	R32	T38	170	6-3/4	55	2-5/32	
7	C3-R38-T38-180-55	R38	T38	180	7-1/8	55	2-5/32	
8	C3-R38-T45-180-63	R38	T45	180	7-1/8	63	2-31/64	
9	C3-T38-T45-180-60	T38	T45	180	7-1/8	60	2-3/8	<b>A</b> <b>B</b>
10	C3-T45-T51-225-72	T45	T51	225	8-7/8	72	2-27/32	
11	C3-T51-T68-225-96	T51	T68	225	8-7/8	96	3-3/4	Adapter Coupling- Full Bridge Type